## One page explanation




**PRE**: prior to the test

**HOT**: "ready to go"

STA: On the KP

FIN: FINished



\* Manual start: TRIP

> Restore **HOT** status: **RESET** (long)

\*\* Only Regularity

1.Change Average Speed manually: SETUP2.Activate next character: STAGES3.Activate Average Speed: DIM

1.Change Average Speed from list: STAGES2.Select next Average Speed: STAGES3.Activate Average Speed: DIM

Forward/stop/reverse: RESET (short)